





100% of Actual Size  
Screen Print

POSITION A




100% of Actual Size  
Pad Print

POSITION D




POSITION E




Please note when pen is printed in position D,  
print is not visible when in the notebook holder.

100% of Actual Size  
Direct Digital

POSITION D




POSITION E




Please note when pen is printed in position D,  
print is not visible when in the notebook holder.


100% of Actual Size  
Pad Print




100% of Actual Size  
Screen Print (one colour)



100% of Actual Size  
Direct Digital



100% of Actual Size  
**BACK** Pad Print



100% of Actual Size  
**BACK** Screen Print (one colour)

